

AIR PRESSURE SENSOR - 46682-0920MOD

The Air Pressure Sensor provides pressure or vacuum readings when installed.



Installation Instructions

- The sensor itself can be mounted outside the seed/fertiliser bin. It should be mounted using the ¼" mounting bolt fixed to the rear of the sensor.
- A 1/8" BSP threaded hole must be tapped into the bin for the included air hose fitting. This pressure hose connection is vital to the sensor's correct operation, as it establishes the pressure difference between inside and outside the bin.

Colour Code

Red	= +8 VDC
Black	= Ground
Green	= Output Signal

Specifications

Sensor Range	= 0 - 10 kPa
Resolution	= 96Hz / 1kPa
Offset	= 200hz
Sensor Scale	0.00 kPa = 200 Hz 10.0 kpa = 1160 Hz