

## 5 Manilla St East Brisbane Q 4169

P: 07 3391 8766 F: 07 3891 1761

## **15L/MIN HYDRAULIC VALVE - 46709-2004**

## **Electrical Specifications**

Control Signal: 12 Volts PWM Control Frequency: 200 Hz Maximum Current: 1.5 Amps



When connected to a tractor with Closed Centre Hydraulics Port 2 (Tank Return) is blocked off.

3

Hydraulic Oil **REGULATED OUT**To Hydraulic Motor

9/16" UNO



2

Hydraulic Oil **TANK RETURN** 9/16" UNO



## **Manual Over-Ride**

For manual over-ride of the hydraulic valve, turn the red thumbscrew clockwise to a maximum of 4 1/2 turns to fully open the hydraulic valve.

For automatic control of the valve the red thumbscrew MUST be turned fully anticlockwise until it stops turning.

