


30L/MIN HYDRAULIC VALVE - 46709-2008

Electrical Specifications

Control Signal: 12 Volts PWM

Control Frequency: 200 Hz

Maximum Current: 1.5 Amps



Manual Over-Ride

For manual over-ride of the hydraulic valve, turn the red thumbscrew clockwise to a maximum of 4 1/2 turns to fully open the hydraulic valve.

For automatic control of the valve the red thumbscrew **MUST** be turned fully anti-clockwise until it stops turning.

